


Click your desired wardrobe layout


## Measuring your fitted wardrobes




**Standard Fitted Wardrobe**  
Page 2



**Single-ended Angled Wardrobe**  
Page 3




**Double-ended Angled Wardrobe**  
Page 4




**Back Slope Angled Wardrobe**  
Page 5


## Designing your fitted wardrobes



**End to End**  
Page 6




**Open One End**  
Page 8



**Internal storage**  
Page 10

# Measuring for your fitted wardrobes



**Important:** remember to measure roughly in the position of where the doors will be, rather than flat to the back wall. This is in case the walls bow or taper.

## YOUR MEASUREMENTS

**A** \_\_\_\_\_ mm    **B** \_\_\_\_\_ mm    **C** \_\_\_\_\_ mm

## Using a tape measure



- A** Measure the height of your room, from floor to ceiling, in 3 different places.

Note down the **tallest** height. If the difference between the highest and lowest measurement is over 20mm, please contact us for help.


- B** Measure the length of your space at 3 different heights. Use the **smallest** of the 3 measurements. Be sure to do this above the skirting boards.

If the difference between the highest and lowest measurement is over 20mm, **please contact us**.

- C** Measure the depth that you'd like your wardrobe to be. This is the external depth, to include the back panel and doors. We recommend a minimum depth of 620mm if you'd like hanging rails.

# Measuring for your **single ended** angled wardrobe

## Dimensions



## Using a tape measure



- A** Measure the **full width**, at floor level, from one wall to the other.
  - B** Measure the **full height** from floor to ceiling.
  - C** Measure the **ceiling width** from the wall to the start of the angled slope.
  - D** Measure the **wall height** from the floor to the start of the angled slope.
- Measure the Height at the start of the angled slope.**
- F** Measure the **Depth of the wardrobe**. We recommend a minimum of 620mm if you want hanging rails.


**Important:** remember to measure roughly in the position of where the doors will be, rather than flat to the back wall. This is in case the walls bow or taper.

## YOUR MEASUREMENTS

**A** \_\_\_\_\_ mm   **B** \_\_\_\_\_ mm   **C** \_\_\_\_\_ mm   **D** \_\_\_\_\_ mm   **E** \_\_\_\_\_ mm   **F** \_\_\_\_\_ mm

# Measuring for your **double ended** angled wardrobe

## Dimensions



## Using a tape measure



- A** Measure the full width of your aperture.
- B+C** Measure the height of the wall at each end from the floor to the start of the angled slope.
- D+E** Measure the height of the wall at each end from the floor to the top of the angled slope.
- F+G** Measure the width of the angled slope on each side of the room.
- H** Measure the Depth of the wardrobe. We recommend a minimum of 620mm if you want hanging rails.


**The overlap on the doors** depends on the chosen profile and is normally about 35-50mm.

**Important:** remember to measure roughly in the position of where the doors will be, rather than flat to the back wall. This is in case the walls bow or taper.

### YOUR MEASUREMENTS

**A** \_\_\_\_\_ mm    **B** \_\_\_\_\_ mm    **C** \_\_\_\_\_ mm    **D** \_\_\_\_\_ mm  
**E** \_\_\_\_\_ mm    **F** \_\_\_\_\_ mm    **G** \_\_\_\_\_ mm    **H** \_\_\_\_\_ mm

# Measuring for your **back sloped** angled wardrobe



## Using a tape measure



- A** Measure the **full width**, at floor level, from one wall to the other.
- B** Measure the **ceiling width** at the top of the angled slope.
- C** Measure the **full height** from floor to ceiling. Make sure to measure from depth point E.
- D** Measure the **wall height** from the floor to the start of the angled slope.
- E** Measure the **Depth of the wardrobe**. We recommend a minimum of 620mm if you want hanging rails.


**Important:** remember to measure roughly in the position of where the doors will be, rather than flat to the back wall. This is in case the walls bow or taper.

## YOUR MEASUREMENTS

**A** \_\_\_\_\_ mm   **B** \_\_\_\_\_ mm   **C** \_\_\_\_\_ mm   **D** \_\_\_\_\_ mm   **E** \_\_\_\_\_ mm


# Designing your fitted wardrobe (end to end)

Draw your wall as a rectangle on a sheet of paper




# Designing your fitted wardrobe (end to end)

## Include the side scribe panels




# Designing your fitted wardrobe (one open end)





# Designing your fitted wardrobe (one open end)

## Include the side scribe and end panels



# Designing your fitted wardrobe (Internal Options)

Choose from our range of [internal option modules](#) and work out what you want to go in each section



2327mm

4500mm

# Need more help?



If you have read this document and still need more help, contact us through our website



[www.online-bedrooms.co.uk](http://www.online-bedrooms.co.uk)

or by phone.



0115 718 0322




One of our friendly, expert wardrobe designers are there to help plan your dream fitted bedroom.



We're with you, helping every step of the way, so you can be enjoying your new wardrobes in no time!



**Planning grid**



← → SCALE 1:200 (1 SQUARE ON GRID = 200MM)



[www.online-bedrooms.co.uk](http://www.online-bedrooms.co.uk)